INSTRUCTIONS TRACTION BLOCKS

Daily maintenance EW159T:

- Only discharge the battery to 80% maximum (Electrolyte level 1130 SG)
- Connect the battery to the charger, switch on charger and charging should start automatically
- Do not disconnect the battery until charge cycle has finished
- When charge cycle has completed make sure charger is switched off before disconnecting the DC plug

Weekly maintenance EW159T:


- Check the level of the Electrolyte on the battery
  Only top up battery with demineralised water

- Only top up after charge cycle has completed
- The battery should only need topping up every 2 weeks
- If required more frequently please contact the manufacturer

- Check for signs of corrosion on cables or bolts clean as required

- The battery tops should be kept clean and dry
  No smoking or naked flames to be in the area of charging

Only top up the battery after the charging cycle has been completed to avoid electrolyte spilling from the battery!
No smoking or naked flames to be in the area of charching.



Green is maximum level

Red is minimum level







Always follow the manufactures instructions

No smoking or naked flames

Electrical Hazard

Danger risk of explosion

Always wear the correct PPE

Avoid contact of skin and eyes

Room must be well ventilated

All disused batteries must be recycled

Berg Hortimotive BV
Burg. Crezeelaan 42a 2678 KZ DE LIER

T : 0174- 517700
F : 0174- 516958

E : info@berghortimotive.com
I : www.berghortimotive.com