


# Quick start BeNomic Star 300/350



## Buttons and switches



1 Main switch



2 Foot pedal




3 Lift wheels



4 Lower wheels



5 Door (push to open)



## Control panel



6 Direction button

7 Speed button

8 Emergency button


9 Platform button

Start here

## Switch on



## Move




Lift wheels Button right

Now you can move the machine


Lower wheels Button left

### Drive




Step on  
the BeNomic

### Platform up and down




### Emergency stop




Push the  
emergency button

Unlock

### Tilt indication



### Battery empty





### Daily maintenance (end of the day)



Battery check



Battery empty



Cleaning