


RAIN BIRD®




ESP-ME3 Controller
/Controlador
/Programmateur

Special Features Card
Tarjeta de Funciones especiales
Carte des fonctions spéciales

- 1 Turn dial** */Girar dial /Tourner la roue*
- 2 Hold for 3 seconds, then release**
Sostener 3 segundos, luego soltar
Maintenir pendant trois secondes, puis relâcher
- 3 Adjust value** */Ajustar valor /Régler la valeur*



Save Programming
Guardar programas
Enregistrer la programmation



Restore Programming
Restaurar programas
Restaurer la programmation



Set Master Valve by Station
Configurar válvula maestra por estación
Paramétrer la vanne maîtresse en fonction des stations



Set To Odd, Even or Cyclic Watering

Configurar riego impar, par o cíclico

Paramétrer un arrosage pair, impair ou cyclique



Set Rain Sensor Bypass by Station

Desactivar sensor lluvia para alguna estación

Désactivation de la sonda de pluie pour une station



Reset to Factory Defaults

Restablecer a configuración de fábrica


Rétablir les paramètres par défaut



Set Flow Sensor Bypass by Station

Configurar bypass del sensor de caudal por estación

Paramétrer le contournement de la sonde de débit en fonction des stations



Set Interstation Delay

Configurar retraso entre estacione(s)

Paramétrer le délai entre chaque station

