



BIO-EZE 3

BIODEGRADABLE FOAMING ALKALINE DEGREASER

BIO-EZE 3 is a new generation foaming alkaline cleaner designed to be safely used on all kinds of surfaces such as vinyl, leather, fabric and painted surfaces.

BIO-EZE 3 easily and effectively removes dirt, stains, oil and grease. It can also be used as a glass cleaner at dilution rate of 2% to 5%, according to degree of difficulty.

FEATURES AND BENEFITS

- · Highly effective
- Ecologo certified UL-2759 Hard surface cleaner
- High foaming
- Readily biodegradable
- Water soluble
- Phosphate free
- Non corrosive



DIRECTIONS FOR USE

Surfaces to be cleaned

Premises and equipment in agricultural and horticultural industry and equipment and premises in food processing industry. Vehicles, engines, tires and parts.

Soils to be removed

Dirt, soil, food deposits, fats, grease, blood.

Use procedures

Once all food debris is removed, rinse surfaces with hot water and then apply a foam solution of **BIO-EZE 3** with appropriate equipment. Allow to dwell then rinse with hot water to remove all product residue. (Rinse surfaces in contact with food with potable water).

Concentration

Between 2% and 5% (20 ml and 50 ml/litre of water).

Temperature

Between 5 and 60°C.

Dwell time/Operation time

Between 2 to 25 minutes.

Mechanical action

For highly resistant soils, scrub with pad or brush.

NOTE: BIO-EZE 3 may tarnish aluminum surfaces. Pretest before using.

BIO-EZE 3 BIODEGRADABLE FOAMING ALKALINE DEGREASER

PHYSICAL PROPERTIES

Appearence

Odour

Specific gravity @ 20 °C

Viscosity

pН

Flash point (TCC)

Water solubility

Auto ignition temperature

Chlorine

Boiling point

Freezing point

Foaming tendency

Concentration monitoring techniques

Rinsing

Clear, pale yellow liquid	Į
Detergent	

1.02

< 10 cps @ 22°C

10.5

None

Complete

None

None

100°C

Not available

High

Electrical conductivity, refractive index

Excellent

INCOMPATIBILITY

None

WAREHOUSING PRECAUTIONS

Keep containers tightly closed in a dry, cool and well-ventilated place

AVAILABLE SIZES









IMPORTANT

Before using **BIO-EZE 3**, always be sure to read and follow precautions and directions for use appearing on the product's container label, and on the safety data sheet (S.D.S).

FIRST AID MEASURES

Eye contact

Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician.

Skin contact

Rinse skin with water. Wash contaminated clothing before reuse.

Inhalation

Not applicable.

Ingestion

Do not induce vomiting. Drink 1 or 2 glasses of water. Call a physician or Poison Control Centre immediately. Never give anything by mouth to an unconscious person.

PERSONAL PROTECTION









MONTREAL

10,900 rue Secant Anjou, QC H1J 1S5 Tel.: 514-355-4660 Toll free : 1 800-361-8927

EDMONTON

11411-160 Street Edmonton, Alberta T5M 3T7 Tel.: 780-454-3919 Toll free : 1 866-454-3919